

ALSAN[®] FLASHING KIT

ESSENTIAL TOOLS FOR QUICK REPAIRS ON THE JOBSITE

SOPREMA'S ALSAN Flashing Kit provides you with everything you need to make fast, permanent repairs and flashings. Designed with efficiency in mind, each kit comes complete with materials and tools conveniently packaged to maximize your use of time. ALSAN Flashing conforms easily to irregular shapes and its unique formulation makes it perfect for creating quick curing, seamless flashings. As a building owner, ALSAN Flashing provides you with an extremely efficient, cost effective option for quickly making repairs. The easy to follow installation instructions save valuable time when a repair is needed. Each kit comes complete with:

- (1) Quart can of ALSAN Flashing
- (1) 25' Roll of ALSAN Polyfleece
- (1) Application brush
- (1) Pair of disposable gloves

Product #D11001



EASY INSTALLATION

1. Pre-cut the ALSAN Flashing fleece to conform with SOPREMA published details and dry fit to ensure proper sizing.
2. Apply ALSAN Flashing liberally with the supplied brush at a rate of two gallons per 100 ft² to the pipe, wrap the fleece around pipe and coat with an additional layer of ALSAN Flashing.
3. Apply ALSAN Flashing to the taped off field area at a rate of two gallons per 100 ft², lay fleece into the first coat and apply second coating of ALSAN Flashing. Remove the tape.
4. Once cured, apply a final coating of ALSAN Flashing at a rate of two gallons per 100 ft² to the pipe and field, extending approximately 1" past the previous coat.
5. While it is not required, if desired, granules may be broadcast into the final coat of ALSAN Flashing to match the cap sheet.

Please visit SOPREMA.US for complete application instructions and details.



www.soprema.us
310 Quadral Drive, Wadsworth, Ohio 44281
Toll Free: (800) 356-3521 | Tel: (330) 334-0066

REV. 04/2018 - SS1002KIT