

NOTES:

- SOPRA—FLASH UN REINFORCEMENT SHALL BE 6" WIDE AND CENTERED OVER CRACK OR JOINT.
- 2. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS AND APPROVED DETAILS.



310 QUADRAL DRIVE WADSWORTH, OHIO 44281 (330) 334-0066

TITLE NON-MOVING JOINTS OR CRACKS UP TO 1/2" WIDE SCALE NONE TM JP 11/25/09

DRAWING NUMBER HRW-503 REV