



- ALSAN TRAFIK RS FLASH MEMBRANE STRINGER FLASHING HEIGHT AS REQ'D. TO MATCH STAIR TREAD/RISER (TYP.)
- PREPARE, LEVEL & PATCH VERTICAL SUBSTRATES W/ ALSAN RS PASTE AFTER PRIMING & PRIOR TO APPLICATION OF ALSAN TRAFIK RS FLASH MEMBRANE (TYP.)
- 4" (100mm) MIN. ALSAN TRAFIK RS FLASH STRIP APPLIED CENTERED ON TREAD, RISER & WALL INTERSECTIONS (TYP.)
- ALSAN TRAFIK RS FLASH MEMBRANE ON STAIR TREAD & RISER W/ 4" (100mm) MIN. OVERLAP @ TREAD/RISER INTERSECTION.
- INSIDE CORNER REINFORCEMENT. SEE TYP. INSIDE CORNER FLASHING DETAIL.
- OUTSIDE CORNER REINFORCEMENT. SEE TYPICAL BOTTOM OUTSIDE CORNER FLASHING DETAIL.
- PREPARE, LEVEL & PATCH HORIZONTAL SUBSTRATES W/ ALSAN RS MORTAR AFTER PRIMING & PRIOR TO APPLICATION OF ALSAN TRAFIK RS FLASH MEMBRANE.

NOTE:
 APPLY TOPCOAT OF ALSAN RS MORTAR @ ALL TREAD LOCATIONS. FINISH ALL STAIR TREADS W/ACCEPTABLE ALSAN RS TRAFFIC SURFACING (TYP.)

SOPREMA DETAIL DRAWINGS: REFER TO SOPREMA AND OTHER RELATED PUBLISHED DOCUMENTATION, PRODUCT DATA SHEETS (PDS), AND SAFETY DATA SHEETS (SDS) FOR ADDITIONAL INFORMATION. ALL DETAIL DRAWINGS AND RELATED INSTALLATION GUIDELINES ARE PROVIDED BY SOPREMA FOR THE SOLE PURPOSE OF ISSUING A SOPREMA WARRANTY. ACCORDINGLY, THE DETAIL DRAWINGS ARE NOT OFFERED, AND SHOULD NOT BE CONSIDERED, AS A SUBSTITUTE FOR PROFESSIONAL DESIGN SERVICES.

PROJECT: ALSAN TRAFIK RS FULLY REINFORCED WATERPROOFING & SURFACING ENGAGED OPEN STAIRWELL		DRAWN BY: SOPREMA TECHNICAL SUPPORT, DWALDRON	
TITLE:		NO.:	DATE:
		REVISION:	
		DATE: 1-15-2022	DRAWING NUMBER: US.RTR.02.M01A
		SCALE: NTS	



SOPREMA[®]
 US CORPORATE ADDRESS
 310 QUADRAL DRIVE
 WADSWORTH, OHIO 44281
 WWW.SOPREMA.US
 Tel: 330.334.0066

USAGE OF THIS DETAIL IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAILS. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.