

### **ALSAN RS Spill Control Protocol**

In the event of a leak or spill of ALSAN RS PMMA (polymethyl methacrylate) resin, it is important to respond as rapidly as possible to prevent the substance from infiltrating the sewer system, or any other confined space, by building dams out of earth or sand to contain and absorb the substance.

#### **Emergency measures in the event of a leak or spill:**

- Protective breathing apparatus
  - In the case of insufficient ventilation, wear a suitable respirator.
- Eye protection
  - Wear chemical safety glasses and/or a face shield in areas where there is a risk of splashes.
- Prepare an emergency eyebath and quick-drench facilities in the work area.
- Hand protection
  - Gloves made of PVA (polyvinyl alcohol) are recommended.
- Evacuate the area downwind of the leak or the slick of spilt product.
- Find and remove all sources of ignition.
- All equipment used for handling must be earthed.
- Stop the leak, if doing so is not dangerous.
- On land, prevent infiltration into waterways, sewers, basements and closed spaces.
- Absorb or cover with sand, earth or some other non-combustible material and transfer to containers.
- Use non-sparking tools to collect absorbed material.
- Uncured SOPREMA ALSAN RS resins and cleaner agents are considered a hazardous material and must be handled as such, in accordance with local, state and federal regulation. Cured SOPREMA ALSAN RS membranes, resins and primers may be disposed of in standard landfills.