


NOTE:
FLASHINGS NOT SHOWN @ LEFT
SIDE OF STAIRWELL FOR
CLARITY.



- ALSAN TRAFIK RS FLASH MEMBRANE STRINGER FLASHING HEIGHT AS REQ'D. TO MATCH STAIR TREAD/RISER (TYP.)
- PREPARE, LEVEL & PATCH VERTICAL SUBSTRATES W/ ALSAN RS PASTE AFTER PRIMING & PRIOR TO APPLICATION OF ALSAN TRAFIK RS FLASH MEMBRANE (TYP.)
- 4" (100 mm) MIN. ALSAN TRAFIK RS FLASH STRIP APPLIED CENTERED ON TREAD, RISER & WALL INTERSECTIONS (TYP.)
- ALSAN TRAFIK RS FLASH MEMBRANE ON STAIR TREAD & RISER W/ 4" (100mm) MIN. OVERLAP @ TREAD/RISER INTERSECTION.
- INSIDE CORNER REINFORCEMENT. SEE TYP. INSIDE CORNER FLASHING DETAIL.
- OUTSIDE CORNER REINFORCEMENT. SEE TYPICAL BOTTOM OUTSIDE CORNER FLASHING DETAIL.
- PREPARE, LEVEL & PATCH HORIZONTAL SUBSTRATES W/ ALSAN RS MORTAR AFTER PRIMING & PRIOR TO APPLICATION OF ALSAN TRAFIK RS FLASH MEMBRANE.

NOTE:
APPLY TOPCOAT OF ALSAN RS MORTAR @ ALL TREAD LOCATIONS. FINISH ALL STAIR TREADS W/ACCEPTABLE ALSAN RS TRAFFIC SURFACING (TYP.)

SOPREMA DETAIL DRAWINGS: REFER TO SOPREMA AND OTHER RELATED PUBLISHED DOCUMENTATION, PRODUCT DATA SHEETS (PDS), AND SAFETY DATA SHEETS (SDS) FOR ADDITIONAL INFORMATION. ALL DETAIL DRAWINGS AND RELATED INSTALLATION GUIDELINES ARE PROVIDED BY SOPREMA FOR THE SOLE PURPOSE OF ISSUING A SOPREMA WARRANTY. ACCORDINGLY, THE DETAIL DRAWINGS ARE NOT OFFERED, AND SHOULD NOT BE CONSIDERED, AS A SUBSTITUTE FOR PROFESSIONAL DESIGN SERVICES.

PROJECT:		DRAWN BY: SOPREMA TECHNICAL SUPPORT, DWALDRON	
TITLE:		NO.:	DATE:
ALSAN TRAFIK RS FULLY REINFORCED WATERPROOFING & SURFACING ENCLOSED STAIRWELL		REVISION:	
		DATE: 1-15-2022	
		DRAWING NUMBER:	US.RTR.02.M01B
		SCALE:	NTS



US CORPORATE ADDRESS
 310 QUADRAL DRIVE
 WADSWORTH, OHIO 44281
www.soprema.us
 Tel: 330.334.0066

USAGE OF THIS DETAIL IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAILS. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.