

ALSAN® TRAFIK RS 787 CF

WATERPROOFING



ALSAN TRAFIK RS 787 CF is a rapid-setting, proprietary formulation polymethyl methacrylate (PMMA) liquid resin. ALSAN TRAFIK RS 787 CF is an unpigmented resin that must be mixed with a pre-measured and packaged ALSAN RS Color Additive. ALSAN TRAFIK RS 787 CF is designed as a light-duty finish resin for color, aesthetics and protection.

- Extremely durable finish layer
- Quick curing and seamless
- Customizable color finish layer to match your project color needs
- Aesthetic color finish resin used for safety lines, logos or decorative appearance over your waterproofing system
- Great for quick, cost-effective repairs

RELATED PRODUCTS



ALSAN RS COLOR ADDITIVE

ALSAN RS Color Additive is mixed with ALSAN RS TRAFIK RS 787 CF. See ALSAN RS Color Additive color chart for standard and special color options.



ALSAN RS CATALYST POWDER




ALSAN RS Catalyst Powder is a reactive agent used to induce curing of ALSAN TRAFIK RS 787 CF.



ALSAN RS 276 PRIMER

ALSAN RS 276 Primer is utilized to promote adhesion when applying ALSAN TRAFIK RS 787 CF in waterproofing applications.

QUICK FACTS

PACKAGING	8.5 kg resin combined with 1.5 kg color additive		
TRAFFICABLE	1 Hour @ 68°F (20°C)		
RAINPROOF	30-45 Minutes @ 68°F (20°C)		
FULLY CURED	3 Hours @ 68°F (20°C)		
APPLICATION			
	ROLLER	BRUSH	SQUEEGEE



MIXING

1



Materials: ALSAN TRAFIK RS 787 CF, ALSAN RS Catalyst Powder, ALSAN RS Color Additive and proper mixing and measuring tools.

2



Thoroughly mix the resin and color additive in the bucket for 2-4 minutes.

3



For batch mixing, pour off colored product into a clean mixing bucket.

4



Using a slow-speed agitator, catalyze according to the mixing table and temperature on the product data sheet. Mix for an additional two (2) minutes. (Small amounts may also be hand-mixed.)

Surfacing APPLICATION

1



Before mixing materials and starting any work, ensure the area is clean and dry. Prepare and mask off application areas with masking tape.

2



Pour catalyzed resin onto the prepared substrate. Provide sufficient material to cover the surface. Consult the product specifications for project coverage rates.

3



Evenly distribute catalyzed liquid resin with a 1/4 in nap roller or flat blade squeegee.

4



Immediately back roll with a dry roller to even out the application. Then remove the masking tape.

5



The surface will be rainproof in 45-60 minutes. If needed, additional layers can be added at this time.

6



Finished surface. No further sealing is necessary. The area is trafficable and can be returned to regular service after one hour.