



FRONT VIEW

NEW OR EXISTING WINDOW (TO REMAIN)

REMOVE EXISTING SEALANT BETWEEN DOOR FRAME & JAMB AS REQUIRED TO INSTALL ALSAN TRAFIK RS 730 MEMBRANE.

APPLY ALSAN TRAFIK RS 730 FLASH MEMBRANE AT WINDOW SILL & SIDE JAMBS EXTENDING & TERMINATED BEHIND WINDOW FRAME.

APPLY SOPRAMATIC SP1 OR ACCEPTABLE SEALANT BETWEEN WINDOW FRAME & ALSAN TRAFIK RS 730 MEMBRANE AS REQUIRED. (TYP.)

ALSAN TRAFIK RS 730 FLASH MEMBRANE EXTENDED BEHIND WINDOW FRAME AS REQUIRED OVER PREPARED & PRIMED SUBSTRATE.

ACCEPTABLE ALSAN RS TRAFFIC SURFACING SEE SPECIFICATIONS FOR OPTIONS.

ALSAN TRAFIK RS 733 SELF-LEVELING MORTAR OVER ALSAN TRAFIK RS 730 MEMBRANE.

ALSAN TRAFIK RS 730 FIELD MEMBRANE.

PREPARE, LEVEL & PATCH SUBSTRATE W/ ALSAN TRAFIK RS 733 SELF-LEVELING MORTAR AFTER PRIMING & PRIOR TO APPLICATION OF ALSAN TRAFIK RS 730 MEMBRANE. (TYP.)

2" (50 mm) MINIMUM
OR AS REQ'D. TO
MATCH HEIGHT OF
WALL FLASHING

4" (100 mm)
MINIMUM

ALSAN RS PRIMER OR APPROVED MOISTURE MITIGATION PRIMER APPLIED TO PREPARED SUBSTRATE (TYP.)

SOPREMA DETAIL DRAWINGS: REFER TO SOPREMA AND OTHER RELATED PUBLISHED DOCUMENTATION, PRODUCT DATA SHEETS (PDS) AND SAFETY DATA SHEETS (SDS) FOR ADDITIONAL INFORMATION. ALL DETAIL DRAWINGS AND RELATED INSTALLATION GUIDELINES ARE PROVIDED BY SOPREMA FOR THE SOLE PURPOSE OF ISSUING A SOPREMA WARRANTY. ACCORDINGLY, THE DETAIL DRAWINGS ARE NOT OFFERED, AND SHOULD NOT BE CONSIDERED, AS A SUBSTITUTE FOR PROFESSIONAL DESIGN SERVICES.



US CORPORATE ADDRESS
310 QUADRAL DRIVE
WADSWORTH, OHIO 44281
www.soprema.us
Tel: 330.334.0066

PROJECT:

TITLE:

**ALSAN TRAFIK RS FULLY REINFORCED
WATERPROOFING & SURFACING
EXISTING WINDOW SILL FLASHING**

DRAWN BY: SOPREMA TECHNICAL SUPPORT, DWALDRON

NO.:

REVISION:

DATE:

DATE: 1-15-2024

SCALE: NTS

DRAWING NUMBER:

US.RTR.02.M02D

USAGE OF THIS DETAIL IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAILS.
PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.